


# Adjust Patio Door Rollers

**Tools Needed**

- Flathead Screw Driver



Inconsistent gap



Interlock inconsistent


# Adjust Patio Door Rollers

Before any adjustments, ensure frame is plumb, level and square



- Open door
- Adjust roller height with flathead screwdriver
- Raising roller up or down will square up door

# Adjust Patio Door Rollers



# Adjust Patio Door Rollers



Engage lock

Acceptable alignment