

Remove Slider Sash



Tools Needed
• Gloves

Unlock all locks

Open sash and clear burglar block



Remove Slider Sash



• Burglar Block

- Grab sash at bottom with both hands
- Lift sash up into header
- Tilt bottom of sash out and clear from sill



Remove Slider Sash



Lower sash out of header



Remove Slider Sash



Repeat the same process for the other sash