


# Adjustable Keeper Repair

## Tools Needed

- #1 Phillips screw driver



Loosen both screws, do not remove them

- Move keeper and center with lock
- Tighten both screws